


737-800 Warning systems



FLT CONT ELEC
FUEL APU

FLT CONT

FLY AID
A ON

FLY RUD
B ON

STANDBY
HYD

ALTIMETER FLAPS

YAW DAMPER

DC AMP CPS FREQ

DC VOLTS / AC AMP / AC VOLTS

PER BAT PER BUS

DC AC

STANDBY POWER

DISCONNECT DISCONNECT

ELEC

FUEL

FUEL MANAGER

FUEL

APU

APU

ANTI-ICE

WING ANTI-ICE ENG ANTI-ICE

Hyd


HYD

Doors

Air Cond

AIR COND

ANTI-ICE
HYD
DOORS AIR COND



Possible Single Fault Annunciatic

AUTO SLAT
FAIL

MACH TRIM
FAIL

SPEED TRIM
FAIL

PSEU

